



How to assemble end hoop poles

Clip from the top of the swag down each side alternatively until you reach the bottom. DO NOT clip from right to left or left to right.

MUST be done from the top down.

How to disassemble end hoop poles

Unclip from the bottom of the swag up each side alternatively until you reach the top. DO NOT unclip from right to left or left to right.

MUST be done from the bottom up.

Seasoning your new swag

Wet the canvas thoroughly then dry completely – repeat 3 times.

This process can take up to 3-4 days to complete as canvas must be completely dry each time.